



AllClear Landing Gear Repair Services

AllClear's Repair Services segment is an FAA (3KRR894D) approved repair station specializing in the repair, overhaul, and inspection of landing gear for C-130, F-16, KC-135, P-3, and 707 derivative platforms.



Boeing 707 (E-3, E-6, E-8)
Main Landing Gear



Lockheed L-100 (C-130)
Nose Landing Gear

Quality & Compliance



Product Offering Highlights

- » Rapid capability development
- » Exchange pool
- » OEM partnerships
- » Competitive price and delivery
- » Customer tech support
- » On-site machining capability
- » On-site painting capability
- » Managed repairs program
- » Favorable warranty terms



AllClear Repair Services
15501 SW 29th St.
Suite 101
Miramar, FL 33027

www.GoAllClear.com
acrs@GoAllClear.com





Landing Gear Repair Services

| | P/N | DESCRIPTION | NSN |
|------------|------------------------------|------------------------------------|------------------|
| C-130 | 3001011-3 | Strut Assy Nose Landing Gear | |
| | 3302196-13 | Strut Assy Main Landing Gear Shock | |
| | 3302196-15 | Strut Assy Main Landing Gear Shock | |
| | 3302196-19 | Strut Assy Main Landing Gear Shock | 1620-01-438-6191 |
| | 3303591-1 | Strut Assy Nose Landing Gear | 1620-00-505-1184 |
| | 3303591-3 | Strut Assy Nose Landing Gear | 1620-00-505-1184 |
| | 3303595-1 | Strut Assy Nose Landing Gear | 1630-01-391-7191 |
| | 3303595-5 | Strut Assy Nose Landing Gear | 1620-01-648-1905 |
| | 3314203-3 | Strut Assy Nose Landing Gear | 1620-01-045-8540 |
| | 3314205-3 | Strut Assy Nose Landing Gear | |
| | 3316498-1 | Strut Assy Main Landing Gear Shock | 1620-01-170-8325 |
| | 3316498-7 | Strut Assy Main Landing Gear Shock | 1620-00-896-1203 |
| | 3316500-13 | Strut Assy Nose Landing Gear | 1620-01-304-4562 |
| | 3316500-15 | Strut Assy Main Landing Gear Shock | 1620-01-304-7618 |
| | 3401095-11 | Strut Assy Nose Landing Gear | 1620-00-996-8172 |
| | 3635900-1A | Strut Assy Nose Landing Gear | |
| | 363590-5 | Strut Assy Nose Landing Gear | |
| | 363590-7 | Strut Assy Nose Landing Gear | 1620-00-784-5563 |
| | 364653-2A | Strut Assy Nose Landing Gear | 1620-00-111-1417 |
| | 370438-1 | Strut Assy Main Landing Gear Shock | 1620-00-623-8911 |
| | 371671-1 | Strut Assy Nose Landing Gear | 1620-00-613-7201 |
| | 388058-1 | Strut Assy Main Landing Gear Shock | 1620-00-896-1203 |
| | 388058-19 | Strut Assy Main Landing Gear Shock | 1620-01-419-9739 |
| | 388058-9 | Strut Assy Main Landing Gear Shock | 1620-00-306-4360 |
| | 388067-7 | Strut Assy Nose Landing Gear | |
| | 388067-9 | Strut Assy Nose Landing Gear | |
| | 388071-1 | Strut Assy Nose Landing Gear | 1620-00-896-1209 |
| | 388071-3 | Strut Assy Nose Landing Gear | 1620-00-085-2624 |
| | 388071-5 | Strut Assy Nose Landing Gear | 1620-00-784-5556 |
| | 388071-9 | Strut Assy Nose Landing Gear | 1620-00-784-5553 |
| | 396175-11 | Strut Assy Nose Landing Gear | |
| | 396175-13 | Strut Assy Nose Landing Gear | |
| | 396175-17 | Strut Assy Nose Landing Gear | |
| | 695001-9A | Strut Assy Main Landing Gear Shock | 1620-00-111-1418 |
| 9235508-10 | Strut Assy Nose Landing Gear | 1620-01-399-1746 | |

| | P/N | DESCRIPTION | NSN |
|-----|-----------------|-------------------|-----|
| 707 | 65-22100-SERIES | Main Landing Gear | |
| | 65-22113-SERIES | Main Landing Gear | |
| | 65-65040-SERIES | Main Landing Gear | |

| | P/N | DESCRIPTION | NSN |
|-----|------------|-------------------|------------------|
| P-3 | 901918-5 | Nose Landing Gear | 1620-01-482-4581 |
| | 901918-105 | Nose Landing Gear | 1620-01-103-2907 |

| | P/N | DESCRIPTION | NSN |
|--------|--------------|-----------------------------------|------------------|
| KC-135 | 200210078-10 | Shock Strut Assembly | |
| | 200210078-20 | Shock Strut Assembly | |
| | 200210078-30 | Shock Strut Assembly | 1620-01-515-8559 |
| | 200210078-40 | Shock Strut Assembly | 1620-01-515-8560 |
| | 200310056-10 | Side Strut Assembly | 1620-01-511-0037 |
| | 200310056-20 | Side Strut Assembly | 1620-01-511-0039 |
| | 200310057-10 | Upper Side Strut Segment Assembly | 1620-01-511-0042 |
| | 200310057-20 | Upper Side Strut Segment Assembly | 1620-01-511-0041 |
| | 200310059-10 | Trunnion Assembly | 1620-01-511-0043 |
| | 200310059-20 | Trunnion Assembly | 1620-01-511-0045 |
| | 458-56102-1 | Trunnion Assembly | 1620-01-143-1121 |
| | 458-56102-2 | Trunnion Assembly | 1620-01-143-1122 |
| | 458-56106-1 | Drag Brace Assembly | 1620-01-143-3293 |
| | 458-56110-1 | Truck Assembly | 1620-01-143-0384 |
| | 458-56123-1 | Shock Strut Assembly | 1620-01-143-1153 |
| | 458-56123-2 | Shock Strut Assembly | 1620-01-143-1154 |
| | 458-56124-1 | Side Strut Assembly | 1620-01-152-1372 |
| | 458-56124-2 | Side Strut Assembly | 1620-01-148-0436 |
| | 458-56125-1 | Upper Side Strut Segment Assembly | 1620-01-143-3294 |
| | 458-56125-2 | Upper Side Strut Segment Assembly | 1620-01-143-3295 |
| | 458-56130-1 | Lower Side Strut Segment Assembly | 1620-01-144-8474 |
| | 458-56137-1 | Upper Universal Assembly | 1620-01-144-1398 |
| | 458-56137-2 | Upper Universal Assembly | 1620-01-144-1399 |
| | 458-56141-1 | Lower Universal Assembly | 1620-01-143-1152 |
| | 458-56151-1 | Torsion Link Assembly | 1620-01-148-5695 |
| | 7531273-100 | Main Gear Oleo Assembly | 1620-01-038-9101 |
| | 7531273-110 | Main Gear Oleo Assembly | 1620-01-038-9102 |
| | 7531273-120 | Main Gear Oleo Assembly | 1620-01-038-9101 |
| | 7531273-130 | Main Gear Oleo Assembly | 1620-01-038-9102 |
| | 7531273-140 | Main Gear Oleo Assembly | 1620-01-038-9101 |
| | 7531273-90 | Main Gear Oleo Assembly | 1620-01-038-9102 |
| | 8853035-10 | Brake Collar Assembly | 1620-01-153-2012 |
| | 8853035-50 | Brake Collar Assembly | 1620-01-498-2055 |
| | 9927108-10 | Truck Assembly | 1620-01-143-0384 |

| | P/N | DESCRIPTION | NSN |
|------|-------------|--|------------------|
| F-16 | 2006600-105 | Nose Landing Gear Shock Strut Assembly | 1620-01-072-8360 |
| | 2006600-119 | Nose Landing Gear Shock Strut Assembly | 1620-01-098-2749 |
| | 2006600-125 | Nose Landing Gear Shock Strut Assembly | 1620-01-124-9135 |
| | 2006600-127 | Nose Landing Gear Shock Strut Assembly | |
| | 2006600-129 | Nose Landing Gear Shock Strut Assembly | 1620-01-224-7090 |
| | 2006600-131 | Nose Landing Gear Shock Strut Assembly | 1620-01-224-7091 |
| | 2006600-135 | Nose Landing Gear Shock Strut Assembly | |
| | 2006600-139 | Nose Landing Gear Shock Strut Assembly | |
| | 2006600-143 | Nose Landing Gear Shock Strut Assembly | 1620-01-225-5457 |
| | 2006600-147 | Nose Landing Gear Shock Strut Assembly | 1620-01-202-6349 |
| | 2006600-151 | Nose Landing Gear Shock Strut Assembly | |
| | 2006600-155 | Nose Landing Gear Shock Strut Assembly | 1620-01-162-7518 |
| | 2006600-169 | Nose Landing Gear Shock Strut Assembly | 1620-01-474-1634 |
| | 2006100-123 | Main Landing Gear Shock Strut Assembly | 1620-01-442-0946 |
| | 965595-50 | Main Landing Gear Shock Strut Assembly | 1620-01-450-3214 |
| | 2007100-103 | Main Landing Gear Shock Strut Assembly | 1620-01-252-1051 |
| | 2007100-105 | Main Landing Gear Shock Strut Assembly | |